

TM  


User Manual / 사용자 매뉴얼 /  
產品手冊 / 产品手册  
Model: VAPPP199

---

## **Introduction:**

Thank you for choosing this Verbatim product. Please read this manual carefully prior to use so as to fully understand the product and its correct usage.

- Type C Port (Input: Max. 18 W / Output: Max. 20 W) - Use to recharge power pack and charge other devices.
- Wireless Charging (Max. 15 W) - Use to charge iPhone, AirPods, Smartphone.

---

## **Caution:**

- When used correctly, lithium-ion and lithium-polymer rechargeable batteries provide a safe and dependable source of portable power. However, misuse & abuse may result in leakage, fire, burns, explosion/disassembly causing personal injury or damage or defects to other devices.
- Do not alter, modify or disassemble the charging device. There are no user-serviceable parts inside, and incorrect reassembly may result in shock or fire hazard.
- Do not drop or subject the charging device to strong mechanical shock.
- Keep the charging device away from heat sources, direct sunlight, combustible gas, humidity, water or other liquids.
- Do not insert any objects into the ports or openings of the charging device.
- Do not operate the charging device if it has been dropped or otherwise damaged in anyway.
- The charging device will generate heat with charging. Always charge in a well ventilated area. Do not charge under pillows, blankets, on flammable surfaces, or in environments where the temperatures exceed 35°C/95°F.
- Keep out of reach of children.
- To reduce the risk of electric shock, unplug the charging device from any power source before attempting maintenance and cleaning.
- Do not short-circuit the charging device or store it in a receptacle where it may be short-circuited by other metallic or conductive objects.

---

## **Package Contents:**

- 1 x Power Pack
- 1 x Type C to Type C Cable
- 1 x Metallic Ring

---

## Specifications:

Battery type: Li-Polymer

Operating temperature: -10°C - 40°C

Cycle time: Above 500 cycles

Size: 105.3 x 63.8 x 10.4mm

Weight: 122g

---

## Input & Output Specifications:

Input: Type C (PD 3.0) - 5 V == 3 A, 9 V == 2 A (Max. 18 W)

Output: Type C (PD 3.0) - 5 V == 3 A, 9 V == 2.22 A, 12 V == 1.7 A (Max. 20 W)

Wireless charging - 5 W, 7.5 W, 10 W, 15 W

Total: Max. 20 W

---



Wireless charging  
5 W, 7.5 W, 10 W, 15 W



LED Indicators

Type C -

Input: Max. 18 W

Output: Max. 20 W

(Support charging in and out simultaneously)

On/Off Button

## Charging the Power Pack:


- Connect the Type C side of the supplied cable to the Type C port on the power pack.
- Connect the other Type C side of the supplied cable to USB AC adaptor. (eg: USB AC adaptor supplied with your Smartphone).
- The White color LED power status lights display the battery level. When fully charged, all four LED lights will be on.
- LED 1 will be in green color if it is fast charging.
- The LED lights switch off automatically when the charging cable is unplugged.



Green LED light - Fast charging power pack  
White LED light - Battery level

## Wireless Charging

- Place compatible wireless charging device on the charging pad. Wireless charging will be initiated and the LED 1 will turn to blue color indicating wireless charging in process.
- White LED power indicator will turn on.
- If wireless charging not initiated, press the power button to activate the power pack for wireless charging.



### Wireless Charging indicator

White LED light "On" - Standby mode

Blue LED 1 light "On" - Charging mode

Blue LED 1 light "Flashing" - FOD

100%	75%	50%	25%	LED 1
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>

## Charging Smartphones, Tablets and Other Devices:

- Connect your devices to the power pack via your device's regular charging cable, plug it into the Type C port on the power pack.
- The LED Power Indicator will turn on.
- LED 1 will be in green color if it is fast charging.
- The LED Power Indicator will switch off automatically when the charging cable is unplugged.


## LED Indicators:

A flashing white LED light indicates that the power pack is charging. Its position indicates the overall charge percentage with each light representing 25%. The battery is fully charged when all four lights are on.

White LED Indicators indicate remaining charge.

4 White LED Lights - Fully Charged

100% 75% 50% 25%



3 White LED Lights - 75% Charge remaining

2 White LED Lights - 50% Charge remaining

1 White LED Lights - 25% Charge remaining

## Metallic Ring:

- The metallic ring provided can be attached to any other brand of phone to utilise the MagSafe equivalent capabilities.

## Device Disposal:

- Please observe local laws when disposing of electronic devices and batteries.

 Verbatim™



RoHS



廢電池請回收

1 Year Limited Warranty – for further details visit [www.verbatim.com/warranty](http://www.verbatim.com/warranty)

• **Warranty Statement**

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Verbatim Australia Pty Ltd (ABN 39 005 706 374) ("Verbatim") provides the following warranty in relation to its goods ("Product").

The benefits of this warranty are in addition to any rights and remedies imposed by Australian State & Federal legislation that cannot be excluded. Nothing in this warranty is to be interpreted as excluding, restricting or modifying any State or Federal legislation applicable to the supply of goods and services which cannot be excluded, restricted or modified.

Verbatim warrants that, subject to the exclusions and limitations below, the Product will be free from defects in materials and workmanship for the period specified on the product packaging and/or the website from date of purchase. If a defect appears in the Product before the end of the warranty period and Verbatim finds the Product to be defective in materials and workmanship, Verbatim will at its own discretion repair or replace the Product free of charge. If goods presented for repair are capable of retaining user-generated data, repair of these goods may result in loss of the data.

• **Proof of Purchase**

Proof of purchase shall be required to be eligible for this warranty and to establish the commencement date of this warranty. This warranty is valid for the original purchase only and is not transferrable to a subsequent customer if the Product is sold by the original customer during the warranty period.

The term of your warranty period shall commence from the purchase date appearing on your purchase receipt from an authorised distributor, reseller or retailer and extends only for the time set forth in the Product documentation. This information can be obtained from the packaging and/or the Verbatim Australia website.

• **Returned Merchandise Authorisation**

No product may be returned to Verbatim Australia without first contacting us for a RMA (Returned Merchandise Authorisation) number. If it is determined that a

Product may be defective, you will be given an authorisation number and instructions for Product return. An unauthorised return, i.e. one for which an RMA number has not been issued, will be returned to you at your expense. Authorised returns are to be shipped prepaid and insured to our Head Office in qualified packaging.

- **Warranty Claims**

- 1) If a fault covered by warranty occurs, the customer must first:
  - a) Contact Verbatim Australia Head Office using the contact details provided below; or
  - b) Return the Product to the retailer from which the Product was purchased.
- 2) Any warranty claim must be accompanied by:
  - a) Proof of purchase; and b) Full details of the alleged defect.
- 3) If Verbatim or the retailer from which the Product was purchased finds no defect in the Product after inspection and testing, the customer must pay Verbatim's usual costs of service work and testing.
- 4) The customer must bear the cost of the transport to Verbatim or to and from the retailer to make the warranty claim including all insurance of the Product. Verbatim will bear the cost of the return transport to the customer once the claim has been finalised.

- **Exclusions**

The warranty will not apply where:

- 1) The Product has been repaired, altered or modified by someone other than Verbatim or an authorised repair agent;
- 2) The alleged defect in the Product is within acceptable industry variances;
- 3) Verbatim cannot establish any fault in the Product after testing and inspection;
- 4) The Product has been used other than for the purpose for which it was designed;
- 5) The defect in the Product has arisen due to the customer's failure to properly use and maintain the Product in accordance with Verbatim's instructions, recommendations and specifications (including applicable maintenance schedules);
- 6) The Product has been subject to abnormal conditions or use, including environment, temperature, water, fire, humidity, pressure, stress or similar;
- 7) The defect has arisen due to abuse, misuse, neglect or accident.

- The warranty does not extend to:
  - 1) Damage or defects caused by normal wear and tear;
  - 2) General, consequential, punitive, incidental or special damages. These include loss of recorded data, interruption of use, the cost of recovery of lost data, lost profits and the cost of the installation or removal of any Products, the installation of replacement Products, and any inspection, testing or redesign caused by any defect or by the repair or replacement of Products arising from a defect in any Product.
  - 3) Incompatibility or poor performance due to specific computer or hardware used.

- Limitations

Verbatim makes no express warranties or representations other than set out in this warranty.

The replacement of the Product or part of the Product is the absolute limit of Verbatim's liability under this express warranty.

- Contact Details

Verbatim Australia Pty Ltd

Unit 6, 450 Princes Highway, Noble Park, Victoria 3174, Australia

Tel: +61 3 9790 8999      Fax: +61 3 9790 8955

Email: [support@verbatim.com.au](mailto:support@verbatim.com.au)

Website: [www.verbatim.com.au](http://www.verbatim.com.au)

## 소개:

버바팀 제품을 선택하여 주셔서 감사합니다. 제품에 대한 이해와 올바른 사용을 위해 사용 전, 이 매뉴얼을 숙지하여 주시기 바랍니다.

- Type C 포트(입력: 최대 18 W / 출력: 최대 20 W) - 파워팩 및 기타 장치 충전용.
- 무선 충전 (최대 15 W) - 아이폰 충전용, 에어팟, 스마트폰 충전용.

## 주의:

- 올바르게 사용되었을 때, 리튬 이온/리튬 폴리머 충전용 배터리는 안전하고 유용한 휴대용 전원을 제공합니다. 그러나 올바르지 못한 사용은 인명 피해나 장치의 손상을 일으키는 누출, 화재, 폭발 등의 원인이 될 수 있습니다.
- 충전 장치를 수리, 수정, 변경하지 마십시오. 내부에는 사용자가 수리할 수 있는 부품이 없습니다. 잘못된 재조립으로 충격이나 화재의 위험이 발생할 수 있습니다.
- 충전 장치를 떨어뜨리거나 강한 충격을 주지 마십시오.
- 충전 장치를 열기, 직사광선, 가연가스, 습도가 높은 곳이나 물, 다른 액체 등에 노출되지 않도록 하십시오.
- 충전 장치의 포트 등에 어떤 물체를 넣지 마십시오.
- 충전 장치에 낙하, 충격 또는 다른 손상이 가해졌을 경우에는 충전 장치를 작동하지 마십시오.
- 충전 장치는 충전 시 열기를 발생시킵니다. 항상 통풍이 잘 되는 곳에서 충전해 주십시오. 베개 밑, 담요, 가연성 표면으로 이루어진 곳 또는 온도가 35°C / 95°F 이상 되는 곳에서는 사용하지 마십시오.
- 어린이의 손에 닿지 않도록 하십시오.
- 감전의 위험을 줄이기 위해 유지관리 및 청소 전에는 충전 장치의 전원을 분리하여 주십시오.
- 합선이 일어나지 않게 하고, 전도성 물체 또는 금속 물체들에 의해 합선이 일어날 수 있는 곳에 보관하지 마십시오.

## 구성품:

- 1 x 파워팩
- 1 x Type C to Type C 케이블
- 1 x 메탈릭 링

## 제품사양:

배터리 타입: 리튬 폴리머

작동 온도:  $-10^{\circ}\text{C} - 40^{\circ}\text{C}$

가용횟수: 500회 이상

사이즈:  $105.3 \times 63.8 \times 10.4\text{mm}$

무게: 122g

## 입력 및 출력 사양:

입력: Type C (PD 3.0) - 5V == 3A, 9V == 2A (최대 18W)


출력: Type C (PD 3.0) - 5V == 3A, 9V == 2.22A, 12V == 1.7A (최대 20W)

무선충전 - 5W, 7.5W, 10W, 15W

총 최대 20W.



무선충전  
5W, 7.5W, 10W, 15W



LED 상태 표시등

Type C -  
최대 18W 입력  
최대 20W 출력  
(패쓰쓰루 지원.)

On/Off 버튼


## 파워팩 충전하기:

- 제공된 케이블의 Type C 커넥터를 파워팩의 Type C 포트에 연결 하십시오.
- 제공된 케이블의 Type C 커넥터를 USB AC 어댑터(예: 스마트폰과 함께 구성된 USB AC 어댑터)에 연결 하십시오.
- 흰색 LED 상태 표시등은 배터리 상태를 나타냅니다. 완충 시, 4개의 LED 등에 모두 불이 켜집니다.
- 고속 충전 시, LED 1은 녹색불이 켜집니다.
- 충전 케이블이 분리되면 LED 상태 표시등은 자동으로 꺼집니다.



## 무선 충전:

- 호환되는 무선 충전 장치를 충전 패드에 올리십시오. LED1에 파란색 불이 들어오며 무선 충전이 시작됩니다.
- 흰색 LED 상태 표시등이 켜질 것입니다.
- 무선 충전이 시작되지 않으면 on/off 버튼을 눌러 파워팩의 무선 충전을 활성화 하십시오.



### 무선 충전 상태 표시등

흰색 LED 켜짐 - 대기 모드

파란색 LED 1 켜짐 - 충전 모드

파란색 LED 1 깜빡임 - FOD

100%	75%	50%	25%	LED 1
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	

KO

## 스마트폰, 태블릿 및 기타 장치 충전하기:

- 충전 케이블을 이용하여 충전하고자 하는 장치와 파워팩을 연결 하십시오.
- LED 상태 표시등이 켜질 것입니다.
- 고속 충전 시, LED 1은 녹색불이 켜집니다.
- LED 상태 표시등은 충전 케이블이 분리되면 자동으로 꺼집니다.

## LED 상태 표시등:


흰색 LED가 깜빡이는 것은 파워팩이 충전 중임을 뜻합니다. 이 LED로 충전량을 알 수 있으며, LED 한 칸은 25%를 나타냅니다.

배터리가 완전히 충전되면 4개의 LED에 모두 불이 들어옵니다.

100% 75% 50% 25%

흰색 LED램프는 충전량을 나타냅니다.

흰색 LED 4칸 : 충전완료



흰색 LED 3칸 : 75% 충전

흰색 LED 2칸 : 50% 충전

흰색 LED 1칸 : 25% 충전

## 메탈릭 링:

- 메탈릭 링을 타 브랜드 스마트폰에 부착하여 맥세이프 기능을 이용할 수 있습니다.

## 장치의 폐기처분:

- 전자제품/배터리 폐기에 관한 각 지역법을 준수하여 주십시오.

 Verbatim<sup>®</sup>



廢電池請回收

1년의 제한된 품질보증 -

보다 자세한 정보는 [www.verbatim.com/warranty](http://www.verbatim.com/warranty)를 참고 하십시오

KO

## 前言：

感謝您選購並使用VERBATIM產品，為讓您能夠更好的使用本產品的所有功能，請您在正式使用本產品前，仔細閱讀本手冊內所提及的注意事項以及詳細功能操作說明。

- Type C 端口(輸入：最大18 W / 輸出：最大20 W) - 為行動電源和其他裝置充電。
- 無線充電 (最大15 W) - iPhone, AirPods, 智慧型手機等充電用。

## 注意事項：

- 在正確使用時，鋰離子和聚合物鋰離子電池提供安全和可靠的便攜式電源。但是，如果它們被誤用或濫用，則可能導致漏電，燙傷，火災或爆炸/解體，造成人身傷害或損壞其他設備。
- 請不要變更，修改或拆開充電設備。內部沒有用戶可維修的零件。不正確的拆裝可能會導致觸電或火災。
- 請勿摔落或讓充電設備受到強烈的機械性衝擊。
- 保持充電設備遠離熱源，避免陽光直射，可燃氣體，濕氣，水或其他液體。
- 不要插入任何對應以外物體到充電設備的端口或開口。
- 請勿操作已受損的充電設備，包括受到摔落或其他形式的損壞。
- 充電設備在充電期間將產生熱量。請務必在通風良好的地方進行充電。請不要在枕頭，被子下，易燃的表面上，或者在溫度超過35°C/95°F環境中進行充電。
- 放置於讓兒童接觸不到的地方。
- 為了減少觸電危險，在嘗試任何維護或清理前，必須拔除充電設備的任何電源。
- 不要讓充電設備短路或將其存儲於可能因金屬或其他導電物體導致短路的地方。

## 包裝內容：

- 1 x 行動電源
- 1 x Type C 至 Type C連接線
- 1 x 金屬環

## 產品規格：

電池種類: 鋰聚合物電池

運作溫度: -10°C - 40°C

循環充電次數: 500 回以上

體積: 105.3 x 63.8 x 10.4 毫米

淨重: 122克

## 輸入輸出規格：

輸入 : Type C (PD 3.0) - 5V == 3A, 9V == 2A (最大18W)


輸出 : Type C (PD 3.0) - 5V == 3A, 9V == 2.22A, 12V == 1.7A (最大20W)

無線充電 - 5W, 7.5W, 10W, 15W

合共最大輸出20W



無線充電  
5W, 7.5W, 10W, 15W



LED顯示燈

Type C -  
最大18W 輸入  
最大20W 輸出  
(支援同時輸入和輸出電源)

開關鍵


## 為可充式行動電源充電：

- 將附帶Type C 連接線連接到行動電源的Type C端口。
- 將連接線另一端的Type C端口連接到USB AC電源變換器 (例如：智能手機提供的USB AC電源變換器)。
- 白光電源狀態LED指示燈顯示電池電量。當充滿電後，所有四個指示燈會同時亮起。
- 當為行動電源進行快速充電時，LED 1指示燈將顯示為綠色。
- 在拔掉連接線後，LED指示燈將自動關閉。



## 無線充電：

- 把支援無線充電的裝置正確放在充電板上。無線充電將啟動，LED 1 將變為藍色，表示正在進行無線充電。
- 白光電源狀態LED指示燈將亮起。
- 如果無線充電沒有啟動，可按下開關鍵啟動行動電源以進行無線充電。



### 無線充電顯示燈

白光LED燈 “亮起” - 備用狀態

藍光LED 1燈 “亮起” - 進行無線充電中

藍光LED 1燈 “閃爍” - FOD保護

100%	75%	50%	25%	LED 1
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	

## 為智能手機，平板電腦或其他設備充電：

- 使用對應的充電線將您的設備連接到行動電源的Type C端口。
- LED電源狀態指示燈在充電時將亮起。
- 當為設備進行快速充電時，LED 1指示燈將顯示為綠色。
- 在拔掉連接線後，LED指示燈將自動關閉。


## LED 指示燈：

閃爍的白光LED指示燈代表行動電源正在充電。其位置表示整體充電比率，而每盞燈代表25%。在電池充滿電時，所有四個指示燈會同時亮起。

100% 75% 50% 25%

白色LED燈的數目表示電源狀態。

- 4 盞白色LED燈 - 電量全滿
- 3 盞白色LED燈 - 75% 剩餘電量
- 2 盞白色LED燈 - 50% 剩餘電量
- 1 盞白色LED燈 - 25% 剩餘電量



## 金屬環：

- 隨包裝提供一個金屬環，可以黏貼在其他品牌的手機上，便可使用與MagSafe相近的磁吸無線充電功能。

## 正確的棄置此設備：

- 不要隨意扔掉。請遵守當地對回收電器和電池的法律規定。



**Verbatim**



廢電池請回收

1年有限保固 - 詳情請瀏覽 [www.verbatim.com/warranty](http://www.verbatim.com/warranty)

## 前言：

感谢您选购并使用VERBATIM产品，为让您能够更好的使用本产品的所有功能，请您在正式使用本产品前，仔细阅读本手册内所提及的注意事项以及详细功能操作说明。

- Type C 端口(输入：最大18 W / 输出：最大20 W) - 为移动电源和其他装置充电。
- 无线充电 (最大15 W) - iPhone, AirPods, 智慧型手机等充电用。

## 注意事项：

- 在正确使用时，锂离子和聚合物锂离子电池提供安全和可靠的便携式电源。但是，如果它们被误用或滥用，则可能导致漏电，烫伤，火灾或爆炸/解体，造成人身伤害或损坏其他设备。
- 请不要变更，修改或拆开充电设备。内部没有用户可维修的零件。不正确的拆装可能会导致触电或火灾。
- 请勿摔落或让充电设备受到强烈的机械性冲击。
- 保持充电设备远离热源，避免阳光直射，可燃气体，湿气，水或其他液体。
- 不要插入任何对应以外物体到充电设备的端口或开口。
- 请勿操作已受损的充电设备，包括受到摔落或其他形式的损坏。
- 充电设备在充电期间将产生热量。请务必在通风良好的地方进行充电。请不要在枕头，被子下，易燃的表面上，或者在温度超过35°C/ 95°F环境中进行充电。
- 放置于让儿童接触不到的地方。
- 为了减少触电危险，在尝试任何维护或清理前，必须拔除充电设备的任何电源。
- 不要让充电设备短路或将其存储于可能因金属或其他导电物体导致短路的地方。

## 包装内容：

- 1 x 移动电源
- 1 x Type C 至 Type C连接线
- 1 x 金属环

## 产品规格：

电池种类: 锂聚合物电池

运作温度: -10°C - 40°C

循环充电次数: 500 回以上

体积: 105.3 x 63.8 x 10.4毫米

净重: 122克

## 输入输出规格：

输入 : Type C (PD 3.0)-5V == 3A, 9V == 2A (最大18W)


输出 : Type C (PD 3.0)-5V == 3A, 9V == 2.22A, 12V == 1.7A (最大20W)

    无线充电 - 5W, 7.5W, 10W, 15W

    合共最大输出20W



无线充电  
5 W, 7.5 W, 10 W, 15 W



LED显示灯

Type C -  
最大18 W 输入  
最大20 W 输出  
(支持同时输入和输出电源)

开关键


## 为可充式移动电源充电：

- 将附带Type C 连接线连接到移动电源的Type C端口。
- 将连接线另一端的Type C 端口连接到USB AC电源变换器 (例如：智能手机提供的USB AC电源变换器)。
- 白光电源状态LED指示灯显示电池电量。当充满电后，所有四个指示灯会同时亮起。
- 当为移动电源进行快速充电时，LED 1指示灯将显示为绿色。
- 在拔掉连接线后，LED指示灯将自动关闭。



## 无线充电：

- 把支持无线充电的装置正确放在充电板上。无线充电将启动，LED 1 将变为蓝色，表示正在进行无线充电。
- 白光电源状态LED指示灯将亮起。
- 如果无线充电没有启动，可按下开关启动移动电源以进行无线充电。




### 无线充电显示灯

白光LED灯 “亮起” - 备用状态

蓝光LED 1灯 “亮起” - 进行无线充电中

蓝光LED 1灯 “闪烁” - FOD保护



## 为智能手机，平板电脑或其他设备充电：

- 使用对应的充电线将您的设备连接到移动电源的Type C端口。
- LED电源状态指示灯在充电时将亮起。
- 当为设备进行快速充电时，LED 1指示灯将显示为绿色。
- 在拔掉连接线后，LED指示灯将自动关闭。


## LED 指示灯：

闪烁的白光LED指示灯代表移动电源正在充电。其位置表示整体充电比率，而每盏灯代表25%。在电池充满电时，所有四个指示灯会同时亮起。


100% 75% 50% 25%

白色LED灯的数目表示电源状态。


4 盏白色LED灯 - 电量全满




3 盏白色LED灯 - 75% 剩余电量



2 盏白色LED灯 - 50% 剩余电量



1 盏白色LED灯 - 25% 剩余电量



## 金属环：

- 随包装提供一个金属环，可以黏贴在其他品牌的手机上，便可使用与MagSafe相近的磁吸无线充电功能。

## 正确的弃置此设备：

- 不要随意扔掉。请遵守当地对回收电器和电池的法律规定。



**Verbatim**

廢電池請回收

1年有限质保 - 详情请访问 [www.verbatim.com/warranty](http://www.verbatim.com/warranty)