
# QUICK START GUIDE

Verbatim Wireless
Vertical Mouse 2.4G + Bluetooth
Bluetooth x 2 | 2.4G


Verbatim 2.4G + 藍牙無線垂直滑鼠
藍牙 x 2 | 2.4G

## Product Description




1. Silent Left Button
2. Silent Right Button
3. Regular Left Button
4. Regular Right Button
5. Scroll Wheel
6. DPI Switch Button
7. LED Indicator
8. Page Forward Button
9. Page Backward Button
10. Connection Switch Button
11. ON/OFF BUTTON
12. USB Receiver
13. Optical Sensor

## LED Indicator




LED 1: Charging / Low battery indicator
Charging: When charging, LED 1 red light will stay on and will turn off after fully charged.
Low Power Indicator: LED 1 red light flashes slowly.

LED 2: 2.4G mode indicator

LED 3: BT1 mode indicator


LED 4: BT2 mode indicator

## How it works

### Connecting to devices

2.4G Wireless Mode Connection

1. Turn the power switch ON.
2. Remove the USB dongle and insert it into the USB port.
3. Double-click the connection switch button to switch to 2.4G.






4. The mouse is now ready to use.

Bluetooth Mode Pairing Steps:

Pairing your wireless vertical mouse via Bluetooth for the first time

1. Turn the power switch ON.
2. Select Bluetooth connection (BT1 or BT2) to use. Double-click the connection switch button to switch and select Bluetooth mode. The LED indicator will flash slowly. Press the connection mode button for around 3 seconds to enter pairing mode, The LED indicator will flash quickly.



## How it works

3. Turn on the Bluetooth function on your Bluetooth device and select “VB BT1 Mouse” or “VB  BT2 Mouse” depending on the Bluetooth connection selected.
4. The mouse is now ready to use.

Remark:

a. Pairing mode will automatically turn off after about 2 minutes if there is no device connected to the wireless vertical mouse.
b. Bluetooth connection steps may vary depending on the device. Please refer to your device’s user manual for specific instructions.

## Switching the connected devices by different connection mode

User can double-click the connection switch button to choose their desired mode.

## Specifications

- Interface: USB-A
- RF: 2.4 GHz / 16 channels
- Sensitivity: 1000 / 1600 / 2400 dpi
- Bluetooth version: 5.4
- Li-Polymer Battery: 500mAh 1.85Wh / 3.7V
- USB-C Input: 5V⎓300mA
- Operating Systems: Windows 8, Mac OS 10.12, iPad OS 9, Android 6 or higher
- Product Dimensions (LxWxH): 110.82 x 71.83 x 75.36 mm
- Product Weight: 120 g
- Operating Temperature: 0 ~ 35°C
- Storage Temperature: -20 ~ 40°C

## Important Safety Instructions

- Some 2.4 GHz wireless devices (such as wireless keyboard/mouse adapters) may experience interference when placed near USB 3.2 Gen 1 devices or hubs. Connect these devices to USB ports further away if possible.
- Do not stare directly into the optical sensor on the bottom of the mouse. Prolonged or intentional exposure to the sensor light may cause temporary eye strain or discomfort.
- Children using this device should be guided and supervised by an adult to ensure proper and safe usage.
- For safety, use the cable included and certified charger to charge the product.
- Do not throw the product into fire or expose it to heat.
- Do not store the product under high temperature or humid environments.
- Do not expose the device to moisture, water, rain, snow, or spray.
- Do not crush or damage the product.
- Do not use a damaged product.
- Do not dissemble the product or change the structure of it.
- Do not repair the device by yourself. There are no user-serviceable parts inside.
- Do not clean the device with harmful chemicals or detergents.
- Do not submerge the device in water or other solvents - protect it against dampness.

## Important Safety Instructions

- Do not throw the device into household waste.
- A damaged product may pose a hazard. Dispose of it carefully.
- Do not insert any other object into the port or openings of the device.
- To reduce the risk of electric shock, unplug the device from any power source before attempting any maintenance or clearing.
- The device should be stored in a clean and ventilated place at an ambient temperature of -20 ~ 40°C/ -4 ~ 104°F .
- Avoid contact with corrosive materials.

## Battery Safety

- When used correctly, lithium-ion and lithium polymer rechargeable batteries provide a safe and dependable source of portable power. However, if they are misused or abused, this may result in leakage, burns, fire or explosion/disassembly, causing personal injury or damage to other devices
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.

## FAQ

1. **Why is my mouse not working?**
   Make sure the power switch is turned on, the receiver is inserted correctly, and the selected mode matches the connected device.
2. **Why is the cursor not smooth?**
   a) Check whether the mouse has enough power and whether the working surface is suitable.
   b) If use 2.4G, check if there is any interference from other devices. Refer to safety instructions.
3. **Why is Bluetooth not connecting?**
   Confirm that Bluetooth is enabled, the mouse is in pairing mode, and the correct Bluetooth device name is selected.

## Australian Consumer Law (ACL)

**(For Australia Only)**

As a manufacturer and supplier, Verbatim Australia provides an assurance to consumers about what we will do if a defect occurs with a “Product”. These assurances are often referred

to as voluntary warranties. Under the Australian Consumer Law (ACL), these are called “Warranties against Defects”.

It is important to remember that a “Warranty against Defects” is provided in addition to consumer guarantees and does not limit or replace them. As of January 1st 2012, manufacturers/suppliers that choose to provide a “Warranty against Defects” to consumers must provide a document evidencing that the warranty complies with specific Australian Consumer Law requirements. The ACL is administered and enforced jointly by the ACCC, State and Territory consumer protection agencies) and where relevant, ASIC (the ACL Regulators). We are aware of the reforms and have amended

our “Warranty against Defects” statement as a result of changes to the Competition & Consumer Act (CCA). In particular, most changes result from the Australian Consumer.

Law (ACL) sections of the CCA.

Verbatim Australia Pty Ltd (ABN 39 005 706 374)

Warranty against Defects

## Australian Consumer Law (ACL)

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Verbatim Australia Pty Ltd (ABN 39 005 706 374) ("Verbatim") provides the following warranty in relation to its goods ("Product").

The benefits of this warranty are in addition to any rights and remedies imposed by Australian State & Federal legislation that cannot be excluded. Nothing in this warranty is to be interpreted as excluding, restricting or modifying any State or Federal legislation applicable to the supply of goods and services which cannot be excluded, restricted or modified.

Verbatim warrants that, subject to the exclusions and limitations below, the Product will be free from defects in materials and workmanship for the period specified on the product packaging and/or the website from date of purchase.

If a defect appears in the Product before the end of the warranty period and Verbatim finds the Product to be defective in materials and workmanship, Verbatim will at its own discretion repair or replace the Product free of charge.

If goods presented for repair are capable of retaining user-generated data, repair of these goods may result in loss of the data.

## Australian Consumer Law (ACL)

### Proof of Purchase

Proof of purchase shall be required to be eligible for this warranty and to establish the commencement date of this warranty. This warranty is valid for the original purchase only and is not transferrable to a subsequent customer if the Product is sold by the original customer during the warranty period.

The term of your warranty period shall commence from the purchase date appearing on your purchase receipt from an authorised distributor, reseller or retailer and extends only for the time set forth in the Product documentation. This information can be obtained from the packaging and/or the Verbatim Australia website.

### Returned Merchandise Authorisation

No product may be returned to Verbatim Australia without first contacting us for a RMA (Returned Merchandise Authorisation) number. If it is determined that a Product may be defective, you will be given an authorisation number and instructions for Product return. An unauthorised return, i.e. one for which an RMA number has not been issued, will be returned to you at your expense. Authorised returns are to be shipped prepaid and insured to our Head Office in qualified packaging.

### Notice to Customer Relating to Repair of Goods

Verbatim Australia will not accept goods for repair unless we have provided the consumer with a Notice to Customer Relating to Repair of Goods that complies with regulations.

## Australian Consumer Law (ACL)

As the notice relates to the repair of Goods that store user-generated data, the repairer's Notice states that the repair of Goods may result in loss of data. Since it is also our practice to supply refurbished Goods as an alternative to repairing a consumer's defective Goods, our notice specifies that the Goods presented for repair may be replaced by refurbished Goods of the same type rather than being repaired. The Repairer's Notice will be issued at the same time that we issue an RMA number. This statement is also available on the Verbatim Australia website.

### Warranty Claims

1. If a fault covered by warranty occurs, the customer must first: a) Contact Verbatim Australia Head Office using the contact details provided below; or b) return the Product to the retailer from which the Product was purchased.
2. Any warranty claim must be accompanied by: a) Proof of purchase; and b) Full details of the alleged defect.
3. If Verbatim or the retailer from which the Product was purchased finds no defect in the Product after inspection and testing, the customer must pay Verbatim's usual costs of service work and testing.
4. The customer must bear the cost of the transport to Verbatim or to and from the retailer to make the warranty claim including all insurance of the Product. Verbatim will bear the cost of the return transport to the customer once the claim has been finalised.

## Australian Consumer Law (ACL)

### Exclusions

The warranty will not apply where:

1. The Product has been repaired, altered or modified by someone other than Verbatim or an authorised repair agent;
2. The alleged defect in the Product is within acceptable industry variances;
3. Verbatim cannot establish any fault in the Product after testing and inspection;
4. The Product has been used other than for the purpose for which it was designed;
5. The defect i n the Product has arisen due to the customer's failure to properly use and maintain the Product in accordance with Verbatim's instructions, recommendations and specifications (including applicable maintenance schedules);
6. The Product has been subject to abnormal conditions or use, including environment, temperature, water, fire, humidity, pressure, stress or similar;
7. The defect has arisen due to abuse, misuse, neglect or accident.

## Australian Consumer Law (ACL)

**The warranty does not extend to:**

1. Damage or defects caused by normal wear and tear;
2. General, consequential, punitive, incidental or special damages. These include loss of recorded data, interruption of use, the cost of recovery of lost data, lost profits and the cost of the installation or removal of any Products, the installation of replacement Products, and any inspection, testing or redesign caused by any defect or by the repair or replacement of Products arising from a defect in any Product.
3. Incompatibility or poor performance due to specific computer or hardware used.

**Limitations**

Verbatim makes no express warranties or representations other than set out in this warranty.

The replacement of the Product or part of the Product is the absolute limit of Verbatim's liability under this express warranty.

Contact Details

Verbatim Australia Pty Ltd - Unit 6, 450 Princes Highway, Noble Park, Victoria 3174, Australia
Tel: +61 3 9790 8999
Fax:+61 3 9790 8955
Email: support@verbatim.com.au
Website: www.verbatim.com.au
Website: www.verbatimlighting.com.au

## Verbatim Limited Warranty Terms

Verbatim warrants this product to be free from defects in material and workmanship for a period of 2 years from date of purchase.

This warranty excludes batteries.

If this product is found to be defective within the warranty period, it will be replaced at no cost to you.

You may return it with your original cash register receipt to the place of purchase or contact Verbatim.

Product replacement is your sole remedy under this warranty, and this warranty does not apply to normal wear or to damage resulting from abnormal use, misuse, abuse, neglect or accident, or to any incompatibility or poor performance due to the specific computer software or hardware used.

VERBATIM WILL NOT BE LIABLE FOR DATA LOSS OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES, HOWEVER CAUSED, FOR BREACH OF WARRANTIES OR OTHERWISE.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state or country to country.


## Note

Verbatim may at any time revise the content of this user guide without further notice.

## Rights


Copyright © 2026 Verbatim. No part of this document may be reproduced in any form or by any means, for any purpose, without the express written permission of Verbatim. All rights reserved. All other brands and product names referenced herein are property of their respective owners.

# 產品說明




1. 靜音左鍵
2. 靜音右鍵
3. 左鍵
4. 右鍵
5. 滾輪
6. DPI 切換按鈕
7. LED 指示燈
8. 下一頁按鈕
9. 上一頁按鈕
10. 連線切換按鈕
11. 電源開關
12. USB 接收器
13. 光學感應器

## LED 指示燈





LED 1：充電 / 低電量指示燈
充電：充電時，LED 1 紅燈會持續亮起；充滿電後熄滅。
低電量提示：LED 1 紅燈慢速閃爍。
LED 2：2.4G 模式指示燈
LED 3：BT1 模式指示燈
LED 4：BT2 模式指示燈

# 運作方式

## 連接裝置

2.4G 無線模式連線

1. 將電源開關撥至 ON。
2. 取出 USB 接收器，並將其插入 USB 連接埠。
3. 按兩下連線切換按鈕，切換至 2.4G。






4. 滑鼠即可直接使用。

藍牙模式配對步驟：

首次透過藍牙配對無線垂直滑鼠

1. 將電源開關撥至 ON。
2. 選擇要使用的藍牙連線 (BT1 或 BT2)。按兩下連線切換按鈕切換並選擇藍牙模式，LED 指示燈會慢速閃爍。按著連線模式按鈕約 3 秒進入配對模式，LED 指示燈會快速閃爍。



## 運作方式

3. 開啟藍牙裝置的藍牙功能，並依所選連線選擇「VB BT1 Mouse」或「VB BT2 Mouse」。
4. 滑鼠即可直接使用。

備註：

a. 如沒有裝置連接至無線垂直滑鼠，配對模式會在約 2 分鐘後自動關閉。
b. 藍牙連線步驟可能因裝置而異。具體操作請參閱您的裝置使用手冊。

## 以不同連線模式切換已連接裝置

按兩下連線切換按鈕，即可選擇所需模式。

## 規格

- 介面：USB-A
- 無線頻率：2.4 GHz / 16 個頻道
- DPI：1000 / 1600 / 2400 dpi
- 藍牙版本：5.4
- 鋰聚合物電池：500mAh 1.85Wh / 3.7V
- USB-C 輸入：5V⎓300mA
- 支援作業系統：Windows 8, Mac OS 10.12, iPad OS 9, Android 6 或以上版本
- 產品尺寸 (長 x 闊 x 高)：110.82 x 71.83 x 75.36 mm
- 產品重量：120 g
- 操作溫度：0 ~ 35°C
- 儲存溫度：-20 ~ 40°C

## 重要安全說明

- 部分 2.4 GHz 無線裝置 (例如無線鍵盤 / 滑鼠接收器) 靠近 USB 3.2 Gen 1 裝置或集線器時可能會受到干擾。可以的話，請將這些裝置連接至距離較遠的 USB 連接埠。
- 請勿直視滑鼠底部的光學感應器。長時間或刻意暴露於感應器光線下，可能會造成暫時性眼睛疲勞或不適
- 兒童使用本裝置時，應在成人指導及監督下使用，以確保正確及安全操作。
- 為確保安全，請使用隨附的充電線及經認證的充電器為產品充電。
- 請勿將產品投入火中或使其受熱。
- 請勿將產品存放於高溫或潮濕環境。
- 請勿讓裝置接觸濕氣、水、雨、雪或噴霧。
- 請勿擠壓或損壞產品。
- 請勿使用已損壞的產品。
- 請勿拆解產品或改變其結構。
- 請勿自行維修裝置；內部沒有使用者可維修的零件。
- 請勿使用有害化學品或清潔劑清潔裝置。
- 請勿將裝置浸入水或其他溶劑，並應避免受潮。
- 請勿將裝置當作一般家居垃圾棄置。
- 損壞的產品可能造成危險，請小心棄置。
- 請勿將任何其他物件插入裝置的連接埠或開口。
- 為減低觸電風險，在進行任何維護或清潔前，請先從任何電源拔除裝置。

## 重要安全說明

- 裝置應存放於清潔、通風良好的地方，環境溫度為 -20 ~ 40°C / -4 ~ 104°F。
- 避免接觸腐蝕性物質。

## 電池安全

- 正確使用時，鋰離子及鋰聚合物充電電池可提供安全可靠的流動電源。然而，如使用不當或遭濫用，可能導致漏液、灼傷、火災、爆炸或解體，造成人身傷害或其他裝置損壞。
- 將電池投入火中或高溫烤箱，或以機械方式擠壓或切割電池，均可能導致爆炸。

## 常見問題

**1. 為何滑鼠無法運作？**
請確保電源開關已開啟、接收器已正確插入，且所選模式與已連接裝置相符。

**2. 為何游標移動不順暢？**
a) 請檢查滑鼠電量是否充足，以及使用表面是否合適。
b) 如使用 2.4G，請檢查是否受到其他裝置干擾，並參閱安全說明。

**3.** 為何藍牙無法連線？請確認藍牙已啟用、滑鼠處於配對模式，並已選擇正確的 Bluetooth 裝置名稱。

## Verbatim 有限保養條款

Verbatim 保證本產品自購買日起 2 年內不會出現材料及工藝缺陷。本保養不包括電池。如本產品於保養期內證實有缺陷，將免費更換。您可連同原始收銀單據將產品退回購買地點，或聯絡 Verbatim。本保養下您唯一可獲得的補救為更換產品；本保養不適用於正常損耗，亦不涵蓋因異常使用、誤用、濫用、疏忽或意外所造成的損壞，或因所使用的特定電腦軟件或硬件而導致的任何不相容或效能欠佳。無論原因為何，對於資料遺失或任何附帶、相應而生或特殊損害，不論涉及違反保養或其他情況，VERBATIM 概不負責。本保養賦予您特定法律權利；您亦可能享有其他權利，而該等權利會因州份或國家 / 地區而異。

## 注意

Verbatim 可隨時修訂本使用指南的內容，恕不另行通知。

## 權利

版權所有 © 2026 Verbatim。未經 Verbatim 明確書面許可，不得為任何目的、以任何形式或方式複製本文件的任何部分。保留所有權利。本文提及的所有其他品牌及產品名稱均為其各自擁有者的財產。

## Technical Support and Documentation

(EN) To download the user manual, access frequently asked questions or contact the Verbatim support team, please go to – www.verbatim.com/support.

(F) Pour télécharger le manuel d'utilisation, accéder aux questions fréquemment posées ou contacter l'équipe d'assistance Verbatim, veuillez vous rendre sur – www.verbatim.com/support.

(DE) Um die Betriebsanleitung herunterzuladen, auf häufig gestellte Fragen zuzugreifen oder das Verbatim-Supportteam zu kontaktieren, gehen Sie bitte auf – www.verbatim.com/support.

(NL) Om de gebruikershandleiding te downloaden, veelgestelde vragen te raadplegen of contact op te nemen met het Verbatim-ondersteuningsteam, gaat u naar – www.verbatim.com/support.

(IT) Per scaricare il manuale utente, vedere le risposte alle domande più frequenti o contattare il team di Assistenza Verbatim, visita la pagina – www.verbatim.com/support.

(ES) Para descargar el manual de usuario, acceder a las preguntas más frecuentes o ponerse en contacto con el equipo de asistencia de Verbatim, visite – www.verbatim.com/support.

(PT) Para descarregar o manual do utilizador, aceder às perguntas mais frequentes ou contactar a equipa de apoio Verbatim, por favor vá a – www.verbatim.com/support.

(PL) Aby pobrać instrukcję obsługi, uzyskać odpowiedzi na często zadawane pytania lub skontaktować się z zespołem pomocy technicznej, proszę przejść na stronę www.verbatim.com/support.

(RU) Чтобы загрузить руководство пользователя, ознакомиться с часто задаваемыми вопросами или связаться со службой поддержки Verbatim, перейдите по адресу – www.verbatim.com/support.

(CZ) Chcete-li si stáhnout uživatelskou příručku, získat přístup k často kladeným otázkám nebo kontaktovat tým podpory společnosti Verbatim, přejděte na stránku – www.verbatim.com/support.

(HU) A felhasználói kézikönyv letöltéséhez, a gyakran ismételt kérdések eléréséhez vagy a Verbatim ügyfélszolgálatával való kapcsolatfelvételhez kérjük, látogasson el a www.verbatim.com/support weboldalra.

(GR) Για να κατεβάσετε το εγχειρίδιο χρήσης, να αποκτήσετε πρόσβαση στις συχνές ερωτήσεις ή να επικοινωνήσετε με την ομάδα υποστήριξης της Verbatim, παρακαλούμε επισκεφθείτε το – www.verbatim.com/support.

(HR)(SR) Za preuzimanje korisničkog priručnika, pristupite često postavljanim pitanjima ili kontaktirajte Verbatim tim za podršku, idite na – www.verbatim.com/support.

(SK) Ak si chcete stiahnuť používateľskú príručku, získať prístup k často kladeným otázkam alebo kontaktovať tím podpory spoločnosti Verbatim, prejdite na – www.verbatim.com/support.

(RO) Pentru a descărca manualul de utilizare, pentru a accesa întrebările frecvente sau pentru a contacta echipa de asistență Verbatim, vă rugăm să accesați – www.verbatim.com/support.

(TR) Kullanım kılavuzunu indirmek, sık sorulan sorulara erişmek veya Verbatim destek ekibiyle iletişime geçmek için lütfen şu adrese gidin – www.verbatim.com/support.

(TC) 關於常見問題的解答，可以下載產品使用手冊或聯繫Verbatim的支援團隊，請登入 – www.verbatim.com/support。

(SC) 关于常见問題的解答，可以下載產品使用手册或联系Verbatim的支持团隊，請登入 – www.verbatim.com/support。

(KO) 설명서 다운로드, 자주 묻는 질문 확인 또는 버바팀 지원팀에 직접 문의하시려면 www.verbatim.com/support 로 접속하십시오.

(JP) ユーザーマニュアルのダウンロード、よくあるご質問、サポート情報については、www.verbatim.com/support をご参照ください。

www.verbatim.com

- EUROPE/MIDDLE EAST/AFRICA/INDIA: Verbatim GmbH, Düsseldorfer Straße 13, 65760 Eschborn, Germany
- AMERICAS: Verbatim Americas LLC. Charlotte, NC 28262, USA
- AUSTRALIA/ NEW ZEALAND: Verbatim Australia Pty Ltd 36-40 Pacific Drive Keysborough, Victoria, 3173 Australia
- ASIA: Verbatim Hong Kong Ltd, Unit 701, 7/F, Tower 2, South Seas Centre, 75 Mody Road, Kowloon, Hong Kong
- Japan: Verbatim Japan LTD., 2-15-4 Kandatsukasamachi, Chiyoda-ku, Tokyo 101-0048, Japan

FSC
www.fsc.org
MIX
Packaging | Supporting responsible forestry
FSC® C157749

2609

E1703